



F-1A IS TEMPORARY TO SUPPORT  
FRONT OF NOSE DURING INSTALLATION.  
REMOVE F-1A BEFORE  
ADDING NOSE CAP

DO NOT GLUE

