



FORMERS

F1 : 1/16" PLY
 F2, 4, 5, 6 : 1/8" "
 F3, 13 : 1/8" SHEET
 F7 TO 12 : 1/16" "

ADD 1/8" WIDE STRIPS OF CELLULOID
 OVER ALL CABIN FRAME AFTER 'GLAZING'
) REPRESENT COVER STRIPS

