



Construction



RETRACT GEAR MODIFICATIONS

1. Cut away parts C-16, C-10, C-13, C-11 and C-4 as required for clearance of wheel and all retract mechanism in extended and retracted positions.
2. Bend landing gear wire as per drawings, being sure to slip the bearing block and steering arm in place before making the last bend in the top "U" shaped leg. Grind or file a "flat spot" on the portion of the wire that comes in contact with the steering arm locking screw to prevent slippage.
3. Attach bearing block to hardwood rail using bolts and blind nuts.

NOTE:
Retract gear pieces
NOT furnished in kit.
Gray area denotes fixed gear pieces

OK
BLY

