


NOTE:
Retract gear pieces
NOT furnished in kit.
Gray area denotes fixed gear pieces
furnished in kit

Use 5/32" o.d. and wire
and wire gender for use
to bend gear to
this size if retracts are desired.



4. Bend lower yoke and back brace and assemble.
5. Attach the two yokes together as shown, using two pieces of tubing wrapped with wire and soldered.
6. Attach rear of back brace to rear hardwood block as shown.

