



HORIZONTAL STABILIZER

1. Glue S-6 and S-7s to the S-5s as shown in the drawing adjacent to the stab plan.
2. While waiting for the elevator assembly to dry, glue the S-1s, S-3s and S-2 around the edge of one S-4 skin as shown.
3. Cut, fit and install the strip balsa ribs and add the remaining S-4 to complete the "sandwich."
4. Spot glue the elevators in place.
5. When dry, sand the entire assembly to the airfoil shape shown on the fuselage side view.

