

of leading edge and W-22s

g top wing skin and mark
ng skin.

mbly from the plans and

on to W-23 and install it
shown between W-4 and

I then bolt horn on to W-10
ng edge planking.

n wing skin and then glue

nd cut away parts shown as
g below wing front view.

on (as shown) and cut and
ends as shown.

nd W-5 as well as between

inges.

for the remaining panel.

ilt last.

par of each panel to a taper

at on your building surface

n) with each tip raised four

1s, W-1A, W-17 and W-18

on as shown in the drawing

between W-1s.

r mount with W-15s on top

27. Add W-16s next to W-1s.

28. When dry, remove from workbench and add the re-
mainder of wing sheeting, W-11 and finally the leading
edge sheet. Refer to rib views
for leading edge contour.

29. Sand wing to shape and add W-31s and W-32s on top.

30. Invert the wing and add cooler boxes made of W-30s
and W-34s as well as W-35 plywood doublers and W-29
after it is carved and sanded to shape.

