



Note:

For greater clarity and the removal of minor imperfections, the canopy may be waxed with an automotive type paste wax. Put several applications, both inside and out, allowing 24 hours drying time between polishings. Be sure to clean area (remove wax) on surface of canopy that is to be glued to the fuselage.

